



LESOTHO

Maseru Urban

Transfers/tunnels

Weir

Hydraulic station

Water flow direction

Dam

WMA boundary

